
























Bullet Nibs		DIAMETER in mm			LENGTH in mm		
		Head	Nub	Shank	Head	Nub	Total
XA-4158		4.80	–	3.50	11.00	–	30.00
XA-3074		4.72	3.68	3.25	5.72	4.10	22.94
XA-40099		4.50	3.90	3.50	8.00	8.00	32.00
XA-4093		5.91	4.45	4.19	7.12	4.57	23.35
XA-4260		5.97	4.44	4.14	7.11	4.57	34.62
XA-4046-1		5.91	4.75	4.19	7.12	8.50	28.20
XA-9675		6.00	4.88	3.38	8.00	10.80	27.76
XA-8095-3		6.10	4.88	3.38	7.50	7.47	32.50
XA-4156-1		5.89	5.18	4.11	7.06	8.38	30.40
XA-91004		6.48	5.18	–	8.40	7.60	28.70

Conical Nibs		DIAMETER in mm			LENGTH in mm		
		Head	Nub	Shank	Head	Nub	Total
XA-3067		4.20	–	2.75	4.50	–	22.00
XA-8136		4.69	3.50	3.40	5.90	4.19	24.00
XA-8184		4.50	3.70	3.11	5.90	4.18	22.48
XA-4082		4.76	3.68	3.44	5.96	4.24	22.28
XA-4062		5.90	5.33	4.00	7.25	7.00	34.55
XA-90456		7.44	–	5.08	12.35	–	35.65
XA-4097		7.54	–	5.13	11.94	–	30.86
XA-4161		7.72	–	5.51	10.97	–	29.69
XA-3064		8.00	6.00	4.00	7.00	8.00	27.00
XA-3001		8.15	–	6.05	16.00	–	30.00
XA-3006		17.00	–	–	–	–	22.50

Brush Nibs		DIAMETER in mm			LENGTH in mm		
		Head	Nub	Shank	Head	Nub	Total
XA-3058		3.70	–	2.80	15.00	–	28.00
XA-3066		4.48	–	2.90	17.50	–	32.50



porex.com

Porex Corporation  
500 Bohannon Road, Fairburn, GA 30213 USA  
T. +1 770 964 1421 F. +1 770 969 0954  
info.porex.amrs@filtrationgroup.com

Porex Technologies GmbH  
Strangenhäuschen 30, 52070 Aachen, Germany  
T. +49 241 910525-0 F. +49 241 910525-16  
info.porex.emea@filtrationgroup.com

Porex Technologies Sdn Bhd  
Lot P.T. 74, Jalan Hulu Tinggi 26/6, Seksyen 26, Sektor A  
Hicom Industrial Park, 40400 Shah Alam, Selangor Malaysia  
T. +603 5191 3308 F. +603 5192 3308  
info.porex.apac@filtrationgroup.com



# POREX® Nibs - Standard Designs

Children's Markers | Office Products | Applicator Tips



Genuine Porex™ : It works. Every time.




































Since 1961, POREX® Nibs have been the smart choice for leading companies who want to get to market efficiently and need a highly reproducible and reliable supplier that operates on a global scale.

































































- Chisel Nibs
- Mini Stampers
- Bullet Nibs
- Conical Nibs
- Brush Nibs

POREX is the original producer of porous plastic nibs to the writing instrument industry. Today, we continue to set the performance standard for writing nibs supplied for highlighters and children's coloring markers.

POREX Nibs are designed for a broad array of writing instrument applications such as highlighters and children's coloring markers. Molded nibs provide a smooth writing feel and the strength and shape required, either with or without a vent groove. Vented nibs allow for ease of assembly, while ensuring the functionality of the capillary system without ink leakage.

Engineered to meet customer performance specifications, POREX® Nibs are available in a wide selection of standard wedge, bullet, and conical designs. They can also be custom designed to meet customers' specific needs, as well as with special material formulations to optimize capillary systems.

Chisel Nibs		DIAMETER in mm			LENGTH in mm		
		Head	Nub	Shank	Head	Nub	Total
XA-92240		3.70	2.80	2.30	4.20	4.32	17.50
XA-4098		3.66	3.15	2.51	7.09	8.00	30.08
XA-3052		3.95	3.40	3.10	5.80	4.30	22.00
XA-4212		4.62	3.43	3.00	6.60	4.32	23.09
XA-3057		3.96	–	3.53	8.90	–	28.40
XA-3075 (prototype)		3.95	–	3.55	6.80	–	20.00
XA-4291		4.70	3.58	3.00	6.40	7.11	18.08
XA-3036		4.00	–	3.60	9.50	–	18.50
XA-3002		3.62	–	–	–	–	10.50
XA-3003 (prototype)		3.62	–	–	–	–	18.00
XA-3080		4.70	3.65	3.45	6.16	3.94	16.65
XA-4454-2		4.70	3.71	3.45	6.16	3.94	22.81
XA-40000		4.65	3.76	3.15	6.20	–	25.76
XA-4347		4.57	3.81	3.56	5.59	9.53	38.10
XA-4051		4.57	3.81	3.56	7.50	9.52	32.50
XA-3031		5.35	–	3.90	11.30	–	40.00
XA-3062		5.35	3.90	3.21	11.30	8.00	40.00
XA-8334		4.70	4.05	3.50	8.00	4.00	24.50
XA-4407		4.96	4.01	2.59	5.33	10.16	33.05
XA-3051		4.80	4.10	3.00	7.00	4.50	30.00
XA-4150		5.03	4.10	2.55	5.07	4.07	25.12
XA-8094		5.03	–	4.34	8.26	–	27.91
XA-4162		6.00	–	4.34	7.34	–	35.00
XA-4449-1		6.00	–	4.40	7.34	–	34.99
XA-3055		5.00	–	4.50	7.07	–	38.00
XA-3081 (prototype)		5.35	4.53	4.30	11.01	10.00	40.00
XA-3089		5.35	–	4.60	11.30	–	36.90
XA-92411-1		6.11	4.50	3.50	7.68	6.35	23.62
XA-4335		6.11	4.50	4.19	7.48	6.35	23.56
XA-99590-1		5.10	4.70	4.20	8.80	10.00	36.00
XA-4207		5.99	4.78	3.51	7.39	7.01	34.98
XA-4159		5.99	4.88	3.38	7.72	11.36	35.03
XA-90609-1		5.97	5.00	4.06	7.62	10.16	34.29
XA-3044		8.00	–	6.00	13.69	–	28.29
XA-4188		10.00	8.00	6.00	9.00	13.00	34.00

Mini Stampers			DIAMETER in mm			LENGTH in mm			
			Head	Nub	Shank	Head	Nub	Total	
XA-3009			Butterfly	7.80	6.00	4.26	4.00	7.16	23.50
XA-3010			Ant	7.80	6.00	4.26	4.00	7.16	23.50
XA-3011			Smiley Face	7.80	6.00	4.26	4.00	7.16	23.50
XA-3012			Daisy	7.80	6.00	4.26	4.00	7.16	23.50
XA-3013			Bee	7.80	6.00	4.26	4.00	7.16	23.50
XA-3014			Heart	7.80	6.00	4.26	4.00	7.16	23.50
XA-3015			Swirl	7.80	6.00	4.26	4.00	7.16	23.50
XA-3016			Star	7.80	6.00	4.26	4.00	7.16	23.50
XA-4195			"O"	6.78	6.00	4.27	6.08	5.08	23.50
XA-4197			"X"	6.78	6.00	4.27	6.08	5.08	23.50
XA-4198			Moon	6.78	6.00	4.27	6.08	5.08	23.50
XA-4199			Not	6.78	6.00	4.27	6.08	5.08	23.50
XA-4204			Happy	6.78	6.00	4.27	6.08	5.08	23.50
XA-4205			Star	6.78	6.00	4.27	6.08	5.08	23.50
XA-4206			Heart	6.78	6.00	4.27	6.08	5.08	23.50
XA-4211			Arrow	6.78	6.00	4.27	6.08	5.08	23.50
XA-98243			Paw	7.50		5.30	7.10		27.10
XA-98390			Left Shoe	7.50		5.30	7.10		27.10
XA-98391			Right Shoe	7.50		5.30	7.10		27.10
XA-98392			Bow Tie	7.50		5.30	7.10		27.10
XA-98393			Ear	7.50		5.30	7.10		27.10
XA-98394			Nose	7.50		5.30	7.10		27.10
XA-98395			Palm	7.50		5.30	7.10		27.10
XA-98396			Mouth	7.50		5.30	7.10		27.10
XA-98397			Eye	7.50		5.30	7.10		27.10
XA-98856			Basketball	7.50		5.30	7.10		27.10
XA-99586			Basketball	7.50		5.30	7.10		27.10
XA-99587			Snowflake	7.50		5.30	7.10		27.10
XA-99588			Christmas Tree	7.50		5.30	7.10		27.10
XA-90020-90045		A-Z	AZ	7.50		5.30	7.10		27.10
XA-98380-98389		0-9		7.50		5.30	7.10		27.10
XA-3071		  		7.50		5.30	7.10		27.10

3009, 3012, 3013 and 3015 are packed mixed in one carton. 3010, 3011, 3014 and 3016 are packed mixed in one carton.